SMM PROCESS FLOWCHART

INSTALLATIONS DIAGRAMS

PROCESS INSTRUCTIONS AND PICTURES FLOWCHART

ASSEMBLY GUIDELINES

- 1- Open the Platen Frame and label holder.
- 2- Open the Label holder and place the Label in-side and beware the direction
- 3 Push the label inside the body4 Label will come out from platen frame and pull out the label. Close back the platen frame
- 5- After close the Platen frame, insert label to inside the platen frame
- 6 At the same time make a few punch to make sure label feed in side the platen frame.
- 7 Punch for testing the label feeding.















7	~~
Car	1

REV	DATE	REASON	TOOL/JIG DETAIL			STANDARD TIME	MODEL	ASSY NAME.	ASSY No.
\square								KEDO / JUDO	
						DOC. CONT. No.			
						DOC. CONT. NO.			
								ASSY LABEL	\ Ⅰ //
$\left \right\rangle $									

SMM PROCESS FLOWCHART

INSTALLATIONS DIAGRAMS

PROCESS INSTRUCTIONS AND PICTURES FLOWCHART


ASSEMBLY GUIDELINES

- 1- Push in the ink roller holder arm
- 2- hold the holder and turn it ,ink roller will come out
- 3- Push again the ink roller holder arm4 -At the same time take the new ink roller
- and replace to the ink roller holder 5 -make sure the new ink roller assembly at the correct position and make a few punch for testing.













REV	DATE	REASON	TOOL/JIG DETAIL			STANDARD TIME	MODEL	ASSY NAME.	ASSY No.
\square									
\square						DOC. CONT. No.		KENDO / JUDO	
\square								INK CHANGE	
\square									